

VI.5.3D-STARTESP PROGRAM FCST HCL TECHNIQUE STARTESP

Purpose

Technique STARTESP sets the starting date for the Function ESP run.

The starting date is the date ESP uses for carryover if it is available. If carryover is not available on this date then the start of the run is changed to the first day available before this date.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique has one Argument which is the starting date.

This Technique is Universal.

Form of Input

STARTESP date

where date is the starting date for the Function ESP run

Examples

STARTESP 030582

The ESP starting date will be set to March 5, 1982.

STARTESP *-05

The ESP starting date will be set to 5 days before TODAY.